STEP	PAPR Level	PPE Donning
1	Healthcare Worker and Donning Partner drink about 8 fluid ounces of a non-caffeinated beverage outside the patient care area.	
2	Healthcare Worker and Donning Partner remove all jewelry, including rings, necklaces and earrings.	
3	Healthcare Worker and Donning Partner perform hand hygiene.	
4	Healthcare Worker and Donning Partner change into scrubs and washable footwear.	
5	If either the Healthcare Worker or Donning Partner have long hair it should be covered with a surgical cap.	

6	Donning Partner puts on a standard patient care gown.	
7	Gown ties are fastened in a bow at both the neck and at the waist.	
8	Healthcare Worker and Donning Partner put on foot covers.	
9	Healthcare Worker and Donning Partner put on standard patient care mask, perform hand hygiene, and then apply a pair of standard patient care gloves.	
10	Unscrew and remove the side caps of the HEPA filters.	

11	Attach one filter to each side of the PAPR motor unit.	
12	Ensure the bottom port plug is securely screwed into the PAPR unit.	
13	Turn on the PAPR to test airflow using the flow tester according to the manufacturer's directions for use.	
14	Attach the belt to the PAPR motor.	
15	Healthcare Worker removes the gloves and foot covers, placing them in the trash. Healthcare worker removes the standard patient care mask placing it in the trash and performs hand hygiene.	

16	Healthcare Worker dons the plastic boot liners.	
17	Healthcare Worker inspects the selected suit for any tears or manufacturing imperfections.	
18	Healthcare Worker sits on the chair to apply the biological protective suit up to their waist.	
19	Donning Partner assists Healthcare Worker to put on a pair of boot covers.	
20	Healthcare Worker stands up from the chair and puts on the upper portion of the biological protective suit.	

21	Healthcare Worker pulls up the zipper of the suit so that it is just above the waist.	
22	The Healthcare Worker puts on the PAPR motor with the tubing attached, with the Donning Partner's assistance.	
23	Healthcare Worker performs hand hygiene.	
24	Healthcare Worker dons first layer of standard patient care gloves, making sure the gloves are worn under the sleeves of the biological protective suit.	
25	Healthcare Worker dons long cuff purple nitrile gloves, making sure they are worn over the sleeves of the biological protective suit.	

26	The Donning Partner seals the cuffs of the purple gloves to the suit with duct tape, making sure that the tape is tabbed at the end for easy removal.	
27	Donning Partner attaches the PAPR tubing to the hood and turns the PAPR motor on.	
28	Donning Partner assists in placing the hood on the Healthcare Worker's head adjusting to ensure a comfortable fit.	
29	Healthcare Worker pulls the outer layer of the hood over their head. Donning Partner tucks the inner layer of the hood into the suit.	
30	Donning Partner pulls the zipper up to neck level.	

31	Donning Partner removes the paper liner from the sticky side of the zipper flap and seals the zipper closure.	DuPont~
32	Donning Partner may seal the zipper closure with duct tape for additional protection.	hem
33	The Donning Partner pulls the outer layer of the hood down over the Healthcare Worker's shoulders.	
34	Donning Partner performs a safety check.	

Photos provided by: University of Nebraska Medical Center College of Nursing HEROES Project, video of the process is available at www.unmcheroes.org . NOTES		